



HOW TO MEASURE: ROLLER SHADES

Please use a steel tape measure to ensure the proper measurements.
 Measure to the nearest eighth of an inch (1/8").
 Measure each window individually even if they look the same.
 Always measure and record the width first, then height.
 Reversing the width measurement for the height measurement is the most common ordering mistake.



Inside Mount



Step 1. Measure the width of the opening where the roller is to be installed. This is your ordering width. The factory will make the necessary deductions to ensure a proper fit. **DO NOT TAKE A DEDUCTION.**

Step 2. Measure the height of the opening on the left, center, and right. Record the longest of the 3 measurements. This is your ordering height.

Please note: Inside mount measurements represent the exact window opening, do not add to or subtract from your measurements.

Factory deductions:

Shade Type	Shade Width	Tip-to-Tip	Fabric Deduction	Light Gaps	
				Control Side	Idle Side
Spring Roller	up to 72"	- 1/8"	1 1/8"	1/2"	1/2"
Clutch Roller	up to 72"	- 1/8"	1 1/8"	1/2"	1/2"
Clutch Roller	72" to 108"	- 1/8"	1 1/4"	5/8"	1/2"
Clutch Roller	108" to 132"	- 1/8"	1 3/8"	3/4"	1/2"
Clutch Roller	132" to 168"	- 1/8"	1 3/8"	3/4"	1/2"
Motorized	up to 72"	- 1/8"	1 1/8"	1/2"	1/2"
Motorized	72" to 108"	- 1/8"	1 1/8"	1/2"	1/2"
Motorized	108" to 132"	- 1/8"	2 3/8"	1 1/2"	3/4"
Motorized	132" to 168"	- 1/8"	2 1/2"	1 1/2"	7/8"
Magic Lift	up to 108"	- 1/8"	3/4"	3/8"	1/4"
Magic Lift w/Cassette	up to 108"	- 1/8"	7/8"	3/8"	3/8"

Minimum Depth

You'll need this much unobstructed depth, including cranks, handles, locks, etc., to inside mount this treatment.

Flush Mount

For the face of your treatment to be flush with the wall or window frame, your frame depth must be the same or greater than the Flush Mount depth required.

	Minimum Depth Required	Flush Mount	Flush Mount Square Valance	Flush Mount Crown Valance
Spring (Cordless) Roller	1 1/2"	up to 3" (varies by pattern)	3 1/4"	4 7/8"
Clutch Roller up to 72" wide	1/2"	2 1/2"	3 1/4"	4 3/8"
Clutch Roller 72" to 108" wide	5/8"	3"	3 1/4"	4 7/8"
Clutch Roller 108" to 132" wide	5/8"	3"	3 1/4"	4 7/8"
Clutch Roller 132" to 144" wide	5/8"	4"	4 1/4"	5 7/8"
Magic Lift (Cordless) Roller	1 5/8"	3"	3 1/4"	4 7/8"
Cassette Rail System	1 1/4"	3 7/8"	N/A	N/A
3" Curved Fascia	7/8"	3 3/4"	N/A	N/A
4" Curved Fascia	7/8"	4 7/8"	N/A	N/A

Please see next page for Outside Mount.

Outside Mount



- Step 1. Measure the width of the area you wish to cover. Measure in 3 places across the top, center and bottom of the window. Record the largest of the 3 measurements. We recommend adding overlap to reduce light leakage around the blind. See *Recommended Overlap*. This is your ordering width.
- Step 2. Decide if the headrail will be installed on or above the window molding. You will need a flat surface area. Measure the height of the area you wish to cover. This is your ordering height.

Please note: Outside mount measurements represent the exact blind size. PROVIDE EXACT DIMENSIONS. Factory deductions:

Shade Type	Shade Width	Fabric Deduction	Light Gaps	
			Control Side	Idle Side
Spring Roller	up to 72"	1"	1/2"	1/2"
Clutch Roller	up to 72"	1"	1/2"	1/2"
Clutch Roller	72" to 108"	1 1/8"	5/8"	1/2"
Clutch Roller	108" to 132"	1 1/4"	3/4"	1/2"
Clutch Roller	132" to 168"	1 1/4"	3/4"	1/2"
Motorized	up to 72"	1"	1/2"	1/2"
Motorized	72" to 108"	1"	1/2"	1/2"
Motorized	108" to 132"	2 1/4"	1 1/2"	3/4"
Motorized	132" to 168"	2 3/8"	1 3/8"	3/4"
Magic Lift	up to 108"	5/8"	3/8"	1/4"
Magic Lift w/Cassette	up to 108"	3/4"	3/8"	3/8"

	OB Mounting Surface Required	Recommended Overlap - Width	Recommended Overlap - Height
Spring (Cordless) Roller	2"	1 1/2" each side	2" above
Clutch Roller up to 72" wide	1 5/8"	1 1/2" each side	2" above
Clutch Roller 72" to 108" wide	2 1/2"	1 1/2" each side	2" above
Clutch Roller 108" to 132" wide	2 1/2"	1 1/2" each side	2" above
Clutch Roller 132" to 144" wide	2 1/2"	1 1/2" each side	2" above
Magic Lift (Cordless) Roller	1 3/4"	1 1/2" each side	2" above
Cassette Rail System	3 3/4"	1 1/2" each side	2" above
3" Curved Fascia	3 1/8"	1 1/2" each side	2" above
4" Curved Fascia	4 1/8"	1 1/2" each side	2" above

Product Stacking Considerations

The chart shows approximately how much of your window area will be covered when your window treatment is fully raised. If you feel too much of the window will be covered, consider Outside Mount. If space allows, mounting brackets for spring and clutch rollers can be raised higher above the window frame to reduce the amount of window covered by the treatment. Valance treatments such as Cassette Rail System and Fascia conceal the shade when fully raised.



Stacking Chart

Clutch Roller up to 72" wide	up to 2 1/2" (varies by pattern)
Clutch Roller 72" to 108" wide	up to 3 1/2" (varies by pattern)
Clutch Roller 108" to 132" wide	up to 4" (varies by pattern)
Clutch Roller 132" to 144" wide	up to 5" (varies by pattern)
Cassette Rail System	4 1/8"

Spring (Cordless) Roller	up to 3" (varies by pattern)
Magic Lift (Cordless) Roller	up to 4" (varies by pattern)
3" Curved Fascia	4"
4" Curved Fascia	5"