





# HOW TO MEASURE: VERTICAL SHADINGS

Please use a steel tape measure to ensure the proper measurements.  
 Measure to the nearest eighth of an inch (1/8").  
 Measure each window individually even if they look the same.  
 Always measure and record the width first, then height.  
 Reversing the width measurement for the height measurement is the most common ordering mistake.



## Inside Mount



Step 1. Measure the width of the opening at the top, middle, and bottom of window. Record the narrowest of the 3 measurements. This is your ordering width. The factory will make the necessary deductions to ensure a proper fit. **DO NOT TAKE A DEDUCTION.**

Step 2. Measure the height of the opening on the left, center, and right. Record the longest of the 3 measurements. This is your ordering height.

Please note: Inside mount measurements represent the exact window opening, do not add to or subtract from your measurements.

Factory Deductions:

One Way Draw - 1 1/2" from headrail width and 3/4" from fabric height.

Split Draw - 1 1/4" from headrail width and 3/4" from fabric height.

### Minimum Depth

You'll need this much unobstructed depth, including cranks, handles, locks, etc., to inside mount this treatment.


### Flush Mount

For the face of your treatment to be flush with the wall or window frame, your frame depth must be the same or greater than the Flush Mount depth required.

	Minimum Depth Required	Flush Mount
Vertical Shadings	1"	6 1/4"

Please note: Outside mount is recommended for all Vertical Shadings. The vanes and fabric are allowed to operate freely while providing complete fabric coverage, enhanced light control and privacy. Inside mount prevents the end treatment from rotating properly and results in light gaps on the sides of the sheer when vanes are closed. Light gaps will be noticeable at the top and bottom of the shade also.

## Outside Mount



Step 1. Measure the width of the area you wish to cover. Measure in 3 places across the top, center and bottom of the window. Record the largest of the 3 measurements. We recommend adding overlap to reduce light leakage around the blind. See *Recommended Overlap*. This is your ordering width.

Step 2. Decide if the headrail will be installed on or above the window molding. You will need a flat surface area. Measure the height of the area you wish to cover. This is your ordering height.

Please note: Outside mount measurements represent the exact blind size. **PROVIDE EXACT DIMENSIONS.**

Factory Deductions:

One Way Draw - 1 1/4" from headrail width and 1/4" from fabric height.

Split Draw - 1" from headrail width and 1/4" from fabric height.

	OB Mounting Surface Required	Recommended Overlap - Width	Recommended Overlap - Height
Vertical Shadings	1 1/8"	5" each side	5" above

Please see Product Stacking Considerations on the next page.

## Product Stacking Considerations

The chart shows approximately how much of your window area will be covered (stack space) when your window treatment is fully drawn open. If you feel too much of the window will be covered, consider Outside Mount. If space allows, Vertical Shadings can be ordered wider to reduce the amount of window covered by the treatment. Use the "Clear Opening" column (uncovered width) to determine your "Ordered Width". For one way draw, also include in your clear opening measurement the desired amount of fabric overlap on the side opposite the fabric stack.



### Stacking Chart

#### Vertical Shadings - One Way Draw

Ordered Width	Stack Space	Clear Opening
24 1/4	9 3/8	14 7/8
35 3/4	11 3/8	24 3/8
47 1/8	13 3/8	33 3/4
61 1/2	15 7/8	45 5/8
73	17 7/8	55 1/8
84 3/8	19 7/8	64 1/2
95 7/8	21 7/8	74

Ordered Width	Stack Space	Clear Opening
107 3/8	23 7/8	83 1/2
118 3/4	25 7/8	92 7/8
133 1/8	28 3/8	104 3/4
144 5/8	30 3/8	114 1/4
156	32 3/8	123 5/8
167 1/2	34 3/8	133 1/8
179	36 3/8	142 5/8

#### Vertical Shadings - Split Draw

Ordered Width	Stack Space	Clear Opening
45	14	31
62 1/4	17	45 1/4
85 1/8	21	64 1/8
108 1/8	25	83 1/8

Ordered Width	Stack Space	Clear Opening
125 1/4	28	97 1/4
148 1/4	32	116 1/4
165 3/8	35	130 3/8
188 1/4	39	149 1/4